



## Supplemental 996TT V-Flow Installation Procedure

Please follow these steps for proper installation of the OEM MAF waffle into the V-Flow billet Venturi. This must be completed prior to installing the V-Flow into the engine compartment.

1. Remove the MAF waffle from the OEM airbox as shown in the photo. This waffle clips into place and will unsnap from the airbox. Be careful not to damage the waffle as it can be brittle.



2. Install the OEM MAF waffle into the EVO billet Venturi. It will snap into place like it did in the OEM airbox. NOTE: the waffle is concaved and is directional. The concaved section of the waffle is the back side. Install the waffle in the same direction that it was installed in the OEM airbox.

